

BALLAST SERIES



Electronic ballast

- 100-120VAC or 220-240VAC 50/60Hz
- Pre-heat start
- Lamp failure protection
- Audible and visual alarm
- With lamp working time display

Model	Input voltage	Output current	Input power	Lamp holder type	Match with lamp	Start method
ZAP2-170-F6JS (EB-F6)	100-120VAC or 220-240VAC	170mA	4-8W	G5	TUV4W TUV6W	Pre-heat start
ZAP2-170-G6JS (EB-G6)				G10Q	UVT5-404 UVT5-406	
ZAP2-425-F16JS (EB-F16)	100-120VAC or 220-240VAC	425mA	10-17W	G5	TUV11W TUV16W	Pre-heat start
ZAP2-425-G16JS (EB-G16)				G10Q	UVT5-404 UVT5-412 UVT5-416 GPH212T5L-GPH357T5L	
ZAP2-425-G28JS (EB-G28)	100-120VAC or 220-240VAC	425mA	19-28W	G10Q	UVT5-425 UVT5-428 GPH436T5L GPH620T5L	Pre-heat start
ZAP2-425-G35JS (EB-G35)	100-120VAC or 220-240VAC	425mA	30-55W	G10Q	UVT5-430 UVT5-435	Pre-heat start
ZAP2-425-G55JS (EB-G55)	100-120VAC or 220-240VAC	425mA	40-55W	G10Q	UVT5-440 UVT5-455 GPH793T5L GPH843T5L	Pre-heat start
ZAP2-610-F25JS (EB-F25)	100-120VAC or 220-240VAC	610mA	25W	G13	TUV25W	Pre-heat start
ZAP2-370-F30JS (EB-F30)	100-120VAC or 220-240VAC	370mA	30W	G13	TUV30W	Pre-heat start
ZAP2-770-F55JS (EB-F55)	100-120VAC or 220-240VAC	770mA	55-75W	G13	TUV55W	Pre-heat start
ZAP2-770-G55JS (EB-G75)				G10Q	UVT5-433 UVT5-448 UVT5-475 UVT5-487 GHO436T5L-GHO843T5L	



Electronic ballast

- 100-120VAC or 220-240VAC 50/60Hz
- Pre-heat start
- Lamp failure protection
- Audible and visual alarm
- With water flow control switch with delay shutdown function

Model	Input voltage	Output current	Input power	Lamp holder type	Match with lamp	Start method
ZAP2-170-F6YS (EB-F6YS)	100-120VAC or 220-240VAC	170mA	4-8W	G5	TUV4W TUV6W	Pre-heat start
ZAP2-170-G6YS (EB-G6YS)				G10Q	UVT5-404 UVT5-406	
ZAP2-425-F16YS (EB-F16YS)	100-120VAC or 220-240VAC	425mA	10-17W	G5	TUV11W TUV16W	Pre-heat start
ZAP2-425-G16YS (EB-G16YS)				G10Q	UVT5-404 UVT5-412 UVT5-416 GPH212T5L-GPH357T5L	